



Westinghouse

# Thermostats



White Rogers Model #	Partners Choice Part #	Partners Choice Model #	Single Multi- Heat Stage Stage Pump			Programs		Applications				Power Source	Performance Features										Comfort & Convenience Features										Terminals			
			1	2	3	Program Options	Periods Per Day Options	Gas/Oil/Elect	3-Wire Zone Value	Millivolt Compatible	Humidity Control (H) Humidity (D) Dehumidity	(B) Battery (H) Hardwired, (B,H) Battery Powered or Hardwired, (P,S) Power Stealing with Battery Back-up	Auto Changeover	Programmable Fan	Comfort Circulating Fan	Energy Mgt. Recovery	Energy Star	Dual Fuel Heat Pump Control (L) Logic (O) Outdoor Sensor	Dual Fuel heat Stages HP/Gas	Keypad Lockout (T) Total (P) Partial Max/Min	Setpoint Temperature Limits Adjustable	Program Overrides (AV) Adjustable Variable (V)	Variable (P) Current Program	Indoor Remote Sensors Max Number + Thermostat Avg and/or Weighted	Outdoor Remote Sensor	Quick "One Button" Programming	Display Size Sq In	Lighted Display	Audible Feedback	Alkaline Battery Life (years)0	Cool Savings™	Daylight Savings Adjustment (A) Auto (B) Button	Furnace Lockout/ignition Module Reset	Memory Back-up (P) permanent (B) Battery	Warranty (years)	
1F85-0471	919758	1F85-0475	1/1	2/2	3/2	5+1+1, 5+2, 0	4, 0		X	X	X		B, H	X			X	X				X	V			X	4	X§		2+	X	X	X	P	5	RC, RH, C, G, W/E, W2, Y, Y2, O/B, 6, L
1F86-0471	919746	1F86-0475	1/1		1/1	0	0		X	X	X		B, H	X												4.0	X§		2+	X		X	P	5	RC, RH, C, W, Y, O/B	
1F95-1271	919771	1F95-1213	1/1	2/2	3/2	7, 5+1+1, 0	4, 2, 0	X	X	X			B, H	X		X	X			T, P	X	AV				12	X§	X	3			X	P	5	RC, RH, C, W/E, W2, Y, Y2, G, L, O, B	
1F95-1277	919774	1F95-1210	1/1	2/2	3/2	7, 5+1+1, 0	4, 2, 0	X	X	X	X		B, H	X	X	X	X	0+	2/2	T, P	X	AV	1+1	1▼	X	12	X§	X	3	X	A	X	P	5	RC, RH, C, W/E, W2, Y, Y2, G, O, B, 6, L, +, S, -	
1F95-391	919772	1F95-326		2/2	3/2	7-day	4		X			H, D	H	X	X	X	X			H	X	AV	3+1	1		2.3	X	X		B	X	P	5	R, C, G, Y1, Y2, E/W1, W2, O, B, L, SA, SB, SC, OT, HM, HM		
1F95CA-391	919773	1F95CA-339		2/2	3/2	7-day	4		X			H, D	H	X	X	X	X	LO	2/2	T, P	X	AV	3+1	1		2.3	X	X		B	X	P	5	R, C, G, Y1, Y2, E/W1, W2, O, B, L, SA, SB, SC, OT, HM, HM		
1F97-1271	919761	1F97-1209	1/1		1/1	7, 5+1+1, 0	4, 2, 0	X	X		X		B, H	X		X	X			T, P	X	AV				12	X§	X	3		X	P	5	RC, RH, C, W, Y, G, L, O, B		
1F97-1277	920375	1F97-1214	1/1		1/1	7, 5+1+1, 0	4, 2, 0	X	X	X	X		B, H	X	X	X	X			T, P	X	AV	1+1	1▼	X	12	X§	X	3	X	A	X	P	5	RC, RH, C, W, Y, G, O, B, L, 6, +, S, -	

CA = Comfort Alert      ♦ = Heat Pump for Stage 1, Gas/Oil/Electric for 2nd Stage / Emergency      § = Optional Continuous display Light w/ Hardwire Connection      † = Recommended Battery Change Interval is once Per Year  
 † = If F145-1378 outdoor remote sensor is not used, install manufacturers fossil fuel kit for Dual Fuel applications      ▼ = Only One (1) Remote Sensor may Be Used - Either Indoor or Outdoor